

Set overtime and multiple matches

Revision 2026-10-12

Choose overtime, how many matches to run, and the break between matches.

Add an optional overtime period, run more than one match, and set rest between matches.

Choose overtime

1. After **MATCH LENGTH**, open **OVERTIME**.
2. Pick **No Overtime**, **1 Minute Overtime**, or **2 Minute Overtime**.

Choose how many matches

1. On **NUMBER OF MATCHES**, pick a count. The subtitle shows **MATCH** for 1 or **MATCHES** for more than one.
2. If you pick more than one match, on **BREAK LENGTH** pick the rest between matches (**5 Sec**, **10 Sec**, **15 Sec**, **30 Sec**, or **1 Min**).
3. Continue through **ARENA MUSIC** and **READY TO START**, then tap **START**.

When a match finishes

1. During the sequence, periods show as **PERIOD 1** and later periods in order. Overtime (when selected) shows **OVERTIME**.
2. Between segments you may see **Break**.
3. When the sequence finishes, the display shows **MATCH COMPLETE**.